

OCTAFLY RGBW

DMX CONTROL TABLE



3-CH Mode					
CH1	Master Dimmer	000	-	255	Master Dimmer 0 - 100%
CH2	Auto Programs	000	-	009	No Function
		010	-	018	Auto 1
		019	-	027	Auto 2
		028	-	036	Auto 3
		037	-	045	Auto 4
		046	-	054	Auto 5
		055	-	063	Auto 6
		064	-	072	Auto 7
		073	-	081	Auto 8
		082	-	090	Auto 9
		091	-	099	Auto 10
		100	-	108	Auto 11
		109	-	117	Auto 12
		118	-	126	Auto 13
		127	-	135	Auto 14
		136	-	144	Auto 15
		145	-	153	Auto 16
		154	-	162	Auto 17
		163	-	171	Auto 18
		172	-	180	Auto 19
		181	-	189	Auto 20
		190	-	198	Auto 21
		199	-	207	Auto 22
		208	-	216	Auto 23
		217	-	225	Auto 24
		226	-	234	Auto 25
		235	-	255	Sound Control
CH3	Speed/Sensitivity	000	-	255	Auto Programs Speed 0 - 100% / Microphone Sensitivity 0 - 100%

7-CH Mode					
CH1	Mechanic Control	000	-	255	Tilt 1 Rotation
CH2		000	-	255	Tilt 2 Rotation
CH3	Master Dimmer	000	-	255	Master Dimmer 0 - 100% (all LEDs)
CH4	Red	000	-	255	Red dimmer 0-100%
CH5	Green	000	-	255	Green dimmer 0-100%
CH6	Blue	000	-	255	Blue dimmer 0-100%
CH7	White	000	-	255	White dimmer 0-100%

10-CH Mode					
CH1	Mechanic Control	000	-	255	Tilt 1 Rotation
CH2		000	-	255	Tilt 2 Rotation
CH3	Master Dimmer	000	-	255	Master Dimmer 0 - 100% (all LEDs)
CH4	Strobe	000	-	009	no Strobe
		010	-	255	Strobe slow -> fast
CH5	Red	000	-	255	Red dimmer 0-100%
CH6	Green	000	-	255	Green dimmer 0-100%
CH7	Blue	000	-	255	Blue dimmer 0-100%
CH8	White	000	-	255	White dimmer 0-100%
CH9	Auto Programs	000	-	009	No Function
		010	-	018	Auto 1
		019	-	027	Auto 2
		028	-	036	Auto 3
		037	-	045	Auto 4
		046	-	054	Auto 5
		055	-	063	Auto 6
		064	-	072	Auto 7
		073	-	081	Auto 8
		082	-	090	Auto 9
		091	-	099	Auto 10
		100	-	108	Auto 11
		109	-	117	Auto 12
		118	-	126	Auto 13
		127	-	135	Auto 14
		136	-	144	Auto 15
		145	-	153	Auto 16
		154	-	162	Auto 17
		163	-	171	Auto 18
		172	-	180	Auto 19
		181	-	189	Auto 20
		190	-	198	Auto 21
		199	-	207	Auto 22
		208	-	216	Auto 23
		217	-	225	Auto 24
		226	-	234	Auto 25
		235	-	255	Sound Control
CH10	Speed/Sensitivity	000	-	255	Auto Programs Speed 0 - 100% / Microphone Sensitivity 0 - 100%

36-CH Mode					
CH1	Mechanic Control	000	-	255	Tilt 1 Rotation
CH2		000	-	255	Tilt 2 Rotation
CH3	Master Dimmer	000	-	255	Master Dimmer 0 - 100% (all LEDs)
CH4	Strobe	000	-	009	no Strobe
		010	-	255	Strobe slow -> fast
CH5	Red 1	000	-	255	LED 1 red dimming 0-100%
CH6	Green 1	000	-	255	LED 1 green dimming 0-100%
CH7	Blue 1	000	-	255	LED 1 blue dimming 0-100%
CH8	White 1	000	-	255	LED 1 white dimming 0-100%
CH9	Red 2	000	-	255	LED 2 red dimming 0-100%
CH10	Green 2	000	-	255	LED 2 green dimming 0-100%
CH11	Blue 2	000	-	255	LED 2 blue dimming 0-100%
CH12	White 2	000	-	255	LED 2 white dimming 0-100%
CH13	Red 3	000	-	255	LED 3 red dimming 0-100%
CH14	Green 3	000	-	255	LED 3 green dimming 0-100%
CH15	Blue 3	000	-	255	LED 3 blue dimming 0-100%
CH16	White 3	000	-	255	LED 3 white dimming 0-100%
CH17	Red 4	000	-	255	LED 4 red dimming 0-100%
CH18	Green 4	000	-	255	LED 4 green dimming 0-100%
CH19	Blue 4	000	-	255	LED 4 blue dimming 0-100%
CH20	White 4	000	-	255	LED 4 white dimming 0-100%
CH21	Red 5	000	-	255	LED 5 red dimming 0-100%
CH22	Green 5	000	-	255	LED 5 green dimming 0-100%
CH23	Blue 5	000	-	255	LED 5 blue dimming 0-100%
CH24	White 5	000	-	255	LED 5 white dimming 0-100%
CH25	Red 6	000	-	255	LED 6 red dimming 0-100%
CH26	Green 6	000	-	255	LED 6 green dimming 0-100%
CH27	Blue 6	000	-	255	LED 6 blue dimming 0-100%
CH28	White 6	000	-	255	LED 6 white dimming 0-100%
CH29	Red 7	000	-	255	LED 7 red dimming 0-100%
CH30	Green 7	000	-	255	LED 7 green dimming 0-100%
CH31	Blue 7	000	-	255	LED 7 blue dimming 0-100%
CH32	White 7	000	-	255	LED 7 white dimming 0-100%
CH33	Red 8	000	-	255	LED 8 red dimming 0-100%
CH34	Green 8	000	-	255	LED 8 green dimming 0-100%
CH35	Blue 8	000	-	255	LED 8 blue dimming 0-100%
CH36	White 8	000	-	255	LED 8 white dimming 0-100%