ASSEMBLY INSTRUCTIONS **ZENIT® SPIN16**

16 MM TV-SPIGOT WITH FLIP MECHANISM



INTRODUCTION

The optionally available 0.63 inch TV spigot CLZSPIN16 is easy to attach to compatible spotlights and can be folded down and up without any tools when needed.

SAFETY INFORMATION

- 1. Please read this user manual carefully.
- 2. Keep all information and instructions in a safe place.
- 3. Follow the instructions.
- 4. Only use the TV spigot as properly intended.

KEEP AWAY FROM CHILDREN! THE PRODUCT CONTAINS SMALL PARTS AND PACKAGING MATERIAL THAT COULD BE SWALLOWED! PLASTIC BAGS MUST BE KEPT OUT OF THE REACH OF CHILDREN!



ASSEMBLY INSTRUCTIONS (EXAMPLE WITH FLAT PRO G2 SPOTLIGHT)


To install the TV spigot, remove the four screws marked in Figure A in the stand or mounting bracket, remove the mounting plate with the mounting hole from the bracket (Figure B), and insert the TV spigot from behind onto the bracket so that the four screw holes in the mounting bracket and the four threads in the base of the TV spigot are aligned exactly on top of each other. Now screw the TV spigot on to the spotlight's mounting bracket using the four previously removed screws (Figure C).







To unfold the TV spigot, tug the spring-loaded locking bolt toward the arrow to pull it out of the locking hole (Figure), fold the TV spigot forward and let the locking bolt engage in the locking hole, which is offset by 90° (Figure).



MANUFACTURER'S WARRANTY & LIMITATION OF LIABILITY

You can find our current warranty conditions and limitation of liability at: https://cdn-shop.adamhall.com/media/pdf/MANUFACTURERS-DECLARATIONS_CAMEO.pdf

To request warranty service for a product, please contact Adam Hall GmbH, Adam-HAll-Str. 1, 61267 Neu Anspach / Email Info@adamhall.com / 49 (0) 6081 / 9419-0



PROPER DISPOSAL OF THIS PRODUCT

(WASTE ELECTRICAL AND ELECTRONIC EQUIPMENT) (Valid in the European Union and other European countries with waste separation)

This symbol on the product, or the documents accompanying the product, indicates that this appliance may not be treated as household waste. This is to avoid environmental damage or personal injury due to uncontrolled waste disposal. Please dispose of this product separately from other waste and have it recycled to promote sustainable economic activity.


Household users should contact either the retailer where they purchased this product, or their local government office, for details on where and how they can recycle this item in an environmentally friendly manner. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal



SPECIFICATIONS

Article number:	CLZSPIN16
Product type:	Spotlight accessory
Type:	16 mm TV spigot, can be folded up and down without any tools
Compatible spotlights:	FLAT PRO G2 Series, Z120 G2, Z180 G2, ZP100 DTW, ZP200 DTW
Color:	Black / brass-colored
Material:	Cast metal
Dimensions (W \times H \times D):	67.4 x 40.7 x 18 mm
Weight:	0.1 kg

MONTAGEANLEITUNG **ZENIT® SPIN16**





EINFÜHRUNG

Der optional erhältliche 16 mm TV-Zapfen CLZSPIN16 ist einfach an kompatible Scheinwerfer anzubringen und kann bei Bedarf werkzeuglos aus- und eingeklappt werden.

SICHERHEITSHINWEISE

- 1. Lesen Sie diese Anleitung bitte sorgfältig durch.
- 2. Bewahren Sie alle Informationen und Anleitungen an einem sicheren Ort auf.
- 3. Befolgen Sie die Anweisungen.

3. Belongen die die Anweisingen.
4. Verwenden Sie den TV-Zapfen nur in der dafür vorgesehenen Art und Weise.
VON KINDERN FERNHALTEN! DAS PRODUKT ENTHÄLT VERSCHLUCKBARE KLEINTEILE UND VERSCHLUCKBARES VERPACKUNGSMATERIAL! KUNSTSTOFFBEUTEL MÜSSEN AUSSER REICHWEITE VON KINDERN AUFBEWAHRT WERDEN!



MONTAGEANLEITUNG (IM BEISPIEL FLAT PRO G2 SCHEINWERFER)


Zum Montieren des TV-Zapfens entfernen Sie die vier in der Abbildung A markierten Schrauben im Stand- bzw. Montagebügel des Scheinwerfers, nehmen die Montageplatte mit dem Montageloch vom Bügel (Abbildung), setzen den TV-Zapfen von hinten auf den Bügel in der Art, dass die vier Schraublöcher im Montagebügel und die vier Gewinde im Sockel des TV-Zapfens exakt übereinander liegen und schrauben nun den TV-Zapfen mit Hilfe der 4 zuvor entfernten Schrauben am Montagebügel des Scheinwerfers fest (Abbildung).







Zum Ausklappen des TV-Zapfens ziehen Sie den gefederten Verriegelungsbolzen in Pfeilrichtung aus dem Verriegelungsloch (Abbildung D), klappen den TV-Zapfen nach vorne und lassen den Verriegelungsbolzen in das um 90° versetzte Verriegelungsloch einrasten (Abbildung D).



HERSTELLERGARANTIE & HAFTUNGSBESCHRÄNKUNG

Unsere aktuellen Garantiebedingungen und Haftungsbeschränkung finden Sie unter: https://cdn-shop.adamhall.com/media/pdf/MANUFACTURERS-DECLARATIONS_CAMEO.pdf

Im Service Fall wenden Sie sich bitte an Adam Hall GmbH, Adam-Hall-Str. 1, 61267 Neu Anspach E-Mail Info@adamhall.com / +49 (0)6081 / 9419-0



KORREKTE ENTSORGUNG DIESES PRODUKTS

(Gültig in der Europäischen Union und anderen europäischen Ländern mit Mülltrennung)

Dieses Symbol auf dem Produkt oder dazugehörigen Dokumenten weist darauf hin, dass das Gerät am Ende der Produktlebenszeit nicht zusammen mit dem normalen Hausmüll entsorgt werden darf, um Umwelt- oder Personenschäden durch unkontrollierte Abfallentsorgung zu vermeiden. Bitte entsorgen Sie dieses Produkt getrennt von anderen Abfällen und führen es zur Förderung nachhaltiger Wirtschaftskreisläufe dem Recycling zu. Als Privatkunde erhalten Sie Informationen zu umweltfreundlichen Entsorgungsmöglichkeiten über den Händler, bei dem das Produkt erworben wurde, oder über die entsprechenden regionalen Behörden. Als gewerblicher Nutzer kontaktieren Sie bitte Ihren Lieferanten und prüfen die ggf. vertraglich vereinbarten Konditionen zur Entsorgung der Geräte. Dieses Produkt darf nicht zusammen mit anderen gewerblichen Abfällen entsorgt werden



SPEZIFIKATIONEN

Artikelnummer:	CLZSPIN16
Produktart:	Scheinwerferzubehör
Тур:	16 mm TV-Zapfen, werkzeuglos ein- und ausklappbar
Kompatible Scheinwerfer:	FLAT PRO G2 Serie, Z120 G2, Z180 G2, ZP100 DTW, ZP200 DTW
Farbe:	schwarz / messingfarben
Material:	Gussmetall
Abmessungen (B x H x T):	67,4 x 40,7 x 18 mm
Gewicht:	0,1 kg