

QUAD COLOUR LED PAR LIGHT

DMX CONTROL TABLE



2-CHANNEL MODE			
CHANNEL	FUNCTION	VALUE	DESCRIPTION
CH1	Master Dimmer	000 - 255	Master Dimmer (0-100%)
CH2	Colour Macro	000 - 016	Red
		017 - 033	Green
		034 - 050	Blue
		051 - 067	White
		068 - 084	Yellow
		085 - 101	Cyan
		102 - 118	Magenta
		119 - 135	Pink
		136 - 152	Bright Green
		153 - 169	Lavender
		170 - 186	Pale Pink
		187 - 203	Bright Yellow
		204 - 220	Bright Magenta
		221 - 237	Pale Cyan
		238 - 255	Warm White

3-CHANNEL 1 MODE			
CHANNEL	FUNCTION	VALUE	DESCRIPTION
CH1	Master Dimmer	000 - 255	Master Dimmer 0-100%
CH2	Strobe	000 - 255	Stroboscope (Speed 0 - 100%, 1 Hz - 20 Hz)
CH3	Colour Macro	000 - 004	Blackout
		005 - 010	Red
		011 - 015	Green
		016 - 020	Blue
		021 - 025	White
		026 - 030	Yellow
		031 - 035	Cyan
		036 - 040	Magenta
		041 - 045	Pink
		046 - 050	Bright Green
		051 - 055	Lavender
		056 - 060	Pale Pink
		061 - 065	Bright Yellow
		066 - 070	Bright Magenta
		071 - 075	Pale Cyan
		076 - 080	Warm White
	Program	081 - 150	Colour Jumping (speed slow - fast)
		151 - 220	Colour Fading (speed slow - fast)
		221 - 255	Sound Control (mic sensitivity min - max)

3-CHANNEL 2 MODE			
CHANNEL	FUNCTION	VALUE	DESCRIPTION
CH1	Dimmer	000 - 255	Red (0-100%)
CH2	Dimmer	000 - 255	Green (0-100%)
CH3	Dimmer	000 - 255	Blue (0-100%)

4-CHANNEL MODE			
CHANNEL	FUNCTION	VALUE	DESCRIPTION
CH1	Dimmer	000 - 255	Red (0-100%)
CH2	Dimmer	000 - 255	Green (0-100%)
CH3	Dimmer	000 - 255	Blue (0-100%)
CH4	Dimmer	000 - 255	White (0-100%)