

MOONFLOWER

DMX CONTROL TABLE



CHANNEL	VALUE	FUNCTION
CH1	000 - 255	Color selection
CH2	0-9	No rotation
	10-120	Counter-clockwise fast-slow
	121-134	No rotation
	135-245	Clockwise slow-fast
	246-255	No rotation
CH3	1-255	Strobe effect slow-fast
CH4	0-255	Dimmer 0-100%