

## USB Driver Set Up Guide

latest updated: July 9, 2007

- (1) If your digital processor has a USB SW on the back of panel,  
please make sure the SW is locate on “USB” position;
- (2) Copy the folder <<USB Driver>> to your local harddisk, no matter C: or D::
- (3) Connect USB cable to PC, then power on your digital processor unit;
- (4) install FT232BM IC driver file <<ftser2k.sys>>  
IF your PC can auto reconize new hardware(USB),  
    >Just follow the picture in the Foler <auto reconize new hardware>  
    to complete the driver install;

IF your PC can not reconize new hardware(USB),  
    > Open control panel  
    > double click icon Add new Hardware  
    > select the hardware type from list, here is <USB serial port(COM\*)>,  
    then follow the prescription go ahead;  
    > Select the Drive file <<ftser2k.sys>> from Dir <<Drive USB1>>;  
    > Follow the prescription to complete the install

Note:above procedure base on Window2000 or Window-XP operation system.